

BFS XTREME-CLEAN CF

all Temperature Liquid Detergent

chlorine free detergent for the cleaning of bulk tanks & milking plant



INSTRUCTION FOR USE

CIRCULATION CLEANING AFTER MILKING

1. Wash outside of cluster and attach to the jettors.
2. Rinse out system well, using 1.4 litre (3 gallons) of water per unit.
3. Prepare wash solution using 300 ml/45 lt water 75 °C or 450 ml/45 lt cold water. This is sufficient for 5 units. For each additional unit add an extra 9 lt of water.
4. Circulate through the machine for 10 – 12 minutes.
5. Return to trough and retain for evening wash if not using an automatic washer.
6. Rinse out system well, using 14 litres (3 gallons) of water per unit, until all traces of detergent are removed.

BFS XTREME-CLEAN CF

When using a Chlorine free detergent the following should be carried out

- Use peracetic acid in the final rinse to maintain excellent TBC & reduce milk stone formation.
- Carry out an acid detergent / descaler wash weekly using BFS Descaler.
- Carry out a routine protein removal wash using.
- Chlorinated detergent such as Xtrme Clean Liquid, followed by an extra water rinse to eliminate the risk of TCM formation.

SAFETY AND HANDLING

- Causes severe skin burns and eye damage.
- Wear protective gloves, protective clothing, eye protection, face protection.
- Do not breath fumes, vapours, spray.
- In case of contact with eyes, rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- In case of contact with skin or hair, remove immediately all contaminated clothing. Rinse with water.

Batch No: _____

Date of Manufacture: _____

Use by date: _____

Storage: _____

STORAGE

- Do not store in direct sunlight or near heat sources.
- Store above 0 °C.
- Store in a well-ventilated place. Keep cool.

BULK TANK CLEANING

- Manual Brush Washing: use Xtreme Clean CF warm at 60 °C at a rate of 70 ml / 10 lt of water, followed by fresh water rinse.
- Automatic System with bowl: use Xtrme Clean CF at a rate of 300 ml / 45 lt of hot water with a minimum temperature of 75 °C. Automatic Washer: use Xtreme Clean CF at a rate of 0.66% v/v or 300 ml / 45 lt of hot water with a minimum temperature of 75 °C.

